


JET 100



JET 100 SPARE PARTS LIST

No.	Name
1	Fan blade cover
2	Fan blade
3	Lengthened Hexagonal screw
4	Rear cover (cast iron)
5	Wave spring washer
6	Bearing
7	Rotor
8	Parallel pin
9	Stator
10	Switch box cover (upside)
11	Capacitor
12	Rubber ring
13	Nut
14	Cable
15	Earthing screw
16	Spring washer
17	Kammprofile gasket
18	Bolt
19	Nut
20	Wiring terminal
21	Bolt
22	Bolt
23	Cable fixed block
24	Bolt
25	Switch box cover (downside)
26	Motor casing
27	Supporting foot
28	Hexagonal screw
29	Thrower
30	Front end housing
31	O-ring
32	Mechanical seal
33	Impeller
34	Gasket
35	Clamp nut
36	Diffuser
37	O-ring
38	Jet pipe
39	O-ring
40	Nozzle
41	O-ring
42	O-ring
43	Plastic valve cap
44	Pump housing
45	O-ring
46	Brass valve cap
47	Dustproof cover
48	O-ring
49	Valve cap